



LIST OF PARTS

1	Magazine Catch *	21	Slide
2	Ejector	22	Extractor
3	Hammer Strut	23	Firing Pin
4	Hammer Pin	24	Barrel
5	Trigger Pin	25	Recoil Spring Guide
6	Catch Pin *	26	Extractor Spring
7	Hammer Spring	27	Extractor Spring
8	Catch Spring *	28	Firing Pin Spring
9	Trigger Spring	29	Recoil Spring
10	Trigger Bar Spring	30	Pin
11	Pistol Grip	31	Magazine Body
12	Grip Screw	32	Magazine Base
13	Grip Nut	33	Magazine Base Lock
14	Frame	34	Magazine Spring
15	Side Plate	35	Follower
16	Screw	36	Magazine Catch
17	Hammer	37	Magazine Catch Lock
18	Pin (2x)	38	Magazine Catch Lock Pin
19	Trigger	39	Catch Spring
20	Trigger Bar		

Comments:

The parts marked with an asterisk (*) are designed for the version with the magazine catch located at the grip butt.