



## LIST OF PARTS

1	Frame	32	Magazine Catch
2	Slide Stop *	33	Magazine Catch Spring
3	Slide Stop Spring	34	-
4	Slide Stop Spring Pin	35	Magazine Catch Spring Screw
5	Trigger	36	Magazine Body *
6	Trigger Pin (2x)	37	Magazine Base
7	Trigger Bar	38	Magazine Base Lock
8	Trigger Spring	39	Magazine Spring *
9	Pin (2x)	40	Follower
10	Ejector	41	Recoil Spring
11	Sear	42	Recoil Spring Guide
12	Sear Spring	43	Barrel
13	Sear Pin (2x)	44	Slide
14	-	45	Front Sight*
15	-	46	Nut *
16	Hammer	47	Compensator *
17	-	48	Recoil Spring Guide Casing
18	Hammer Pin	49	Cocking Lever*
19	Hammer Pin Retaining Peg	50	Extractor
20	Main Spring Strut	51	Extractor Pin
21	Main Spring	52	Extractor Spring
22	Main Spring Plug	53	Rear Sight *
23	-	54	Firing Pin
24	Magazine Guide	55	Firing Pin Spring
25	-	56	Firing Pin Plate
26	Grip Panel - Left *	57	Adjusting Screw (2x)
27	Grip Panel - Right *	58	Securing Screw
28	Grip Panel Screw (2x)	59	Ejector Spring (2x)
29	a) Safety - Left	60	Magazine Funnel
	b) Safety - Right	61	Slide Stop Pin *
30	a) Safety Detent Plunger - Left	62	Mount for Collimator *
	b) Safety Detent Plunger - Right	63	C-MORE Collimator *
31	Safety Detent Plunger Spring	64	Mount Screw (3x) *

The parts marked \* differ according to versions, or as case may be in some versions are entirely missing.

In order to retain the continuity with lists of parts of other pistols, some numbers are indicated with a hyphen only. This means that these parts are missing in the CZ 75 TS CZECHMATE pistols.